

SafeDial™ wireless GL45-3G



TECHNICAL ADDENDUM DIRECT ALARM PANEL DIALLER CONNECTIONS

Globe Wireless
Level 8 - 499 St Kilda Road Melbourne VIC 3004
www.globetelecom.com.au

Technical Support : 1300 728 650



Background

Globe's GL45-3G module has a terminal block for the connection of the supplied female 611 fly lead. If the Alarm Panel also has a terminal block for PSTN connections, we recommend you use your own cable between the Alarm Panel dialler and GL45-3G. This type of installation negates the use of the female 611 fly lead (supplied), decreasing your installation time.



For Alarm Panels with six (6) pin RJ connectors, please refer to the manufactures wiring diagram – Tecom & Concept are detailed below.

Sample wiring diagrams between Globe's GL45-3G and various popular Alarm Panel types are shown below:

