

CATEGORY	EVENT ID	PARTITION	ZONE (UNIQUE)	DESCRIPTION
SYSTEM ALARMS	313	39	953/954	Engineering Reset (changed encryption key) No action required.
	337	39	950	Expansion Module DC Loss 13.8V DC voltage low or absent.
	350	39	953	Fail to Communicate GL45-3G experienced trouble sending signals does not expect a restore.
	352	39	955/956	Dialler Interface Lead Fail Issue with Dialler lead between GL45-3G unit and the Alarm Panel (4 Wire interface).
	356	39	968	IP Path Poll Fail The GL45-3G failed its poll requests via IP.
	356	39	969	Cellular Network Path Poll Fail The GL45-3G failed its poll requests via cellular network.
	356	39	970	SDW GL45-3G is Offline The GL45-3G is not responding to network requests.
GENERAL ALARMS	140	39	981	Auxiliary 1 — Auxiliary input on SDW-100-3G unit.
	140	39	982	Auxiliary 2 — Auxiliary input on SDW-100-3G unit.
	140	39	983	Auxiliary 3 — Auxiliary input on SDW-100-3G unit.

For more information and FAQ's on any of our products or services please visit us online at www.globetelecom.com.au

Phone 1300 73 73 14

Email support@globetelecom.com.au